

USE DIELECTRIC GREASE (PART #1704378) TO PREVENT CORROSION ON TERMINALS.


STEP 1: Shur-Co.® Wireless Receiver - Identify 6 ga. wire running from electric motor through front pivot arm. Route wire as desired. Insert end of this wire through rubber boots, then crimp 1/4" ring terminals onto wire ends. Remove nuts and lock washers from back of wireless receiver. Place positive wire on upper orange post and negative wire on upper black post. Secure lock washers and hex nuts. Coat with dielectric grease and install rubber boots over ring terminals.

Run a section of 6 ga. wire, long enough to reach the sealed junction box, through rubber boots. Crimp 1/4" ring terminals to wire ends. On back of wireless receiver, place positive wire on lower orange post and negative wire on lower black post. Secure with lock washers and hex nuts. Coat with dielectric grease and install rubber boots over ring terminals.

Mount receiver at suitable location on front of trailer. Mark and drill 11/32" holes and fasten with 5/16" x 7/8" cap screws, flat washers and nylon lock nuts.

STEP 2: Sealed Junction Box - Locate junction box near conductor socket. Mark and drill 3/16" holes and fasten to trailer with 1/4" x 3/4" self-drilling screws.

Run 6 ga. wire from receiver to sealed junction box. Crimp 1/4" ring terminals to wire ends. Remove hex nuts and lock washers from posts in junction box. Place positive wire on positive post and negative wire on negative post.



PO BOX 713 • 2309 SHUR-LOK STREET YANKTON, SOUTH DAKOTA 57078-0713 PH. 1-800-474-8756 • FAX 605-665-0501




Run separate section of 6 ga. wires from conductor socket to sealed junction box. Crimp 1/4" ring terminals to wire ends. Place positive wire on positive post, negative wire on negative post. Run separate section of 6 ga. wires from ProTrap® motor assembly to junction box near conductor socket. Secure with 1/4" lock washers and hex nuts.

Cut wires to length and strip only enough wire insulation to install ring terminals. Insert bare wire into ring terminals and crimp securely.



Fasten conductor socket to mounting bracket. Slide 6 ga. wire through sealed boot. Connect wires to conductor socket. Slide boot against conductor socket. Secure boot to wire with cable tie.



Operation

- **A)** Open Tarp: Check motor direction by activating switch to "OPEN". If switch is running system backwards, change wire leads on motor to opposite connections.
- **B)** Close Trap: Push switch to "CLOSE" and hold. Observe trap and release switch when hopper door is fully closed.
- C) Open Trap: Push switch to "OPEN" and hold. Observe trap and release switch when hopper door is fully opened.


NOTE: Release switch at end of cycle or modified-reset circuit breaker will trip. After breaker resets, switch will activate motor again. To reduce unnecessary strain on tarp components, release switch at end of each cycle.

NOTE: Pressure Wash - The receiver may be pressure washed, but keep nozzle at least three feet from system while spraying.

Replacement Parts

<u>Item</u>	Part #	Description
1.	1704308	Cap Screw - #10 x 1/2"
1. 2. 3. 4. 5. 6. 7. 8.	1704298	Motor Reversing Solenoid - RF Cap Screw - 1/4" x 1 1/2"
3.	1704343	Cap Screw - 1/4" x 1 1/2"
4.	1700408	Hex Nut - 1/4"
5.	1700427	Flat Washer - 1/4"
6.	1118257	Shur-Co.® Wireless Receiver
/.	1118296	Modular Control Bracket
8.		End Plug - 1" x 14-23 Ga.
9.	1703282	Rubber Grommet - 1 1/4" Insert
10.	1118037	Plastic Washer - Black
11. 12	1118250	Plastic Washer - Orange
12. 12	1700436 1118297	Lock Washer - 1/4"
	1118340	Insulating Plate Solenoid Cover w/Decal, Gasket,
14.	1110340	Rocker Switch & 8" Wires
15	1702926	Cap Screw - 5/16" x 7/8"
	1201237	Flat Washer - 5/16"
17	1700419	Nylon Lock Nut - 5/16"
	1704317	12 Ga. Wire - 3" Black
	1704316	12 Ga. Wire - 3" Red
	1704369	Trim Seal
		SMARTransmitter® Remote
22.		

PO BOX 713 **2309** SHUR-LOK STREET YANKTON, SOUTH DAKOTA 57078-0713 PH. 1-800-474-8756 **FAX** 605-665-0501





SHUR-CO.® HELP LINE CALL: 1-866-748-7435 www.shurco.com