


Item	Part #	Description	Qty.
1.	1705549	Fitting - Check/Shuttle Valve - 1/8"	1
2.	1705470	Air Fitting - Male Connector - 1/4" x 1/8" - Dot	2
3.	1705560	Air Fitting - Female Connect - 1/4" x 1/8" - Dot	1

**NOTE:** Apply thread sealant when assembling.

**STEP 1:** When operating manual control air valve, replace tees with parts shown above.



**PLUMB AIR LINES AND AIR FITTINGS AS SHOWN.**