

What to expect from Express Mode on SMART remotes?

On our 4500 Series HD SMART2™ and SMART3™ remotes, the trailer-mounted control boxes now operate in Express Mode. Control boxes have a the bright yellow decal on the front that says “SMART EXPRESS.” Pressing the “O” or “C” button initiates an Express open or close operation. After that, pressing any button on the box stops tarp operation, or it stops automatically at end of travel. On SMART2™, if travel stops are not set, the trailer-mounted control box operates in Manual (momentary) Mode.

Version 11 of our SMART2™ is now shipped with main menu control enabled for easier operation of devices from the main screen. The remote defaults to Express Mode for the tarping system, but only if travel stops are set. Other changes include:

- **Added screen options.** Adjust the time before the remote automatically shuts off. Previously three minutes, this can now be set for two, three, five, 10, 15 or 20 minutes. Or adjust how long before the backlight shuts off. Previously 30 seconds, this can now be set for 15 or 30 seconds or one, two, three or five minutes. Adjusting this time will affect battery life.
- **Improved performance/response.** Lets you quickly lock on to your device/function and makes the screen populate faster. Faster response in Main Menu Mode.
- **Improved battery life.** A plus for users who allow remote to periodically “time out.”
- **Operator notification.** During setting of stops on the SMART2™, the operator will be notified if an encoder wire is not connected.
- **Improved options.** Like the more intuitive, quicker way to delete travel stops.

For additional information about Shur-Co® products, give us a call at **1.800.474.8756** Monday through Friday, from 8:00 a.m. to 5:00 p.m. Central Time. Our friendly and knowledgeable Customer Service Representatives will be happy to answer your questions. Or log on to our website at www.shurco.com.



Top: Our trailer-mounted control box now operates in Express Mode. Bottom left: Version 11 of the SMART2™ is shipped with the main menu control enabled, in addition to other changes and new options. Bottom right: The SMART3™ remote is shipped with the tarp channel set to Express Mode.